













Hardware by Compo

# Head Rest Bracket II (HRB Series)








Compo offer a many types of head rest brackets for upholstery. Each of the brackets are designed for specific application. Customer can choose the correct head rest bracket for their application. Compo head rest brackets uses various type of mechanism for its construction, ranging of PU rubber pretension type, ratchet mechanism, and pressure pads stepless type.

As usual the bracket are made to exacting Compo standard meaning that these bracket will be trouble free for a long time.



Description	Type of Mechanism	Picture
 <p>HRB 1001                      HRB 1002</p>	<ul style="list-style-type: none"> <li>• Stepless pressure plate.</li> <li>• This is a 180° joint which can be used high-low back sofa.</li> </ul>	
 <p>HRB 1101</p>	<ul style="list-style-type: none"> <li>• 4 steps ratchet joint</li> <li>• 30mm extension to remove wrinkle for pillow.</li> <li>• The KD bracket is optional.</li> </ul>	 <p>wrinkle                      Up 40mm</p>
 <p>HRB 1201</p>	<ul style="list-style-type: none"> <li>• 10 steps ratchet operation.</li> <li>• This is a simple ratchet joint commantly used for arm or head rest.</li> <li>• Bend angle 90°</li> <li>• The KD bracket is optional.</li> </ul>	
 <p>HRB 1202</p>	<ul style="list-style-type: none"> <li>• 7 steps ratchet operation.</li> <li>• This is a simple ratchet joint commantly used for arm or head rest.</li> <li>• Bend angle 90°~150°</li> </ul>	
 <p>HRB 1203</p>	<ul style="list-style-type: none"> <li>• 6 steps ratchet operation.</li> <li>• This is a simple ratchet joint commantly used for arm or head rest.</li> <li>• Bend angle 90°~180°</li> </ul>	



Description	Type of Mechanism	Picture
 <p data-bbox="316 501 440 533">HRB 1204</p>	<ul data-bbox="762 219 1069 385" style="list-style-type: none"> <li>• 3 steps ratchet operation.</li> <li>• Simple ratchet joint used for arm rest.</li> <li>• Bend angle 90°-150°</li> </ul>	
 <p data-bbox="306 891 427 922">HRB 1205</p>	<ul data-bbox="762 611 1082 799" style="list-style-type: none"> <li>• 5 steps ratchet operation.</li> <li>• This is a simple ratchet joint commonly used for arm rest.</li> <li>• Bend angle 90°-150°</li> </ul>	
 <p data-bbox="316 1276 437 1308">HRB 1301</p>	<ul data-bbox="762 999 1053 1164" style="list-style-type: none"> <li>• Spring washer plate with 4 steps.</li> <li>• This is extension head rest bracket with head tilt mechanism.</li> </ul>	
 <p data-bbox="316 1666 437 1697">HRB 1302</p>	<ul data-bbox="762 1395 1053 1561" style="list-style-type: none"> <li>• Spring washer plate with 6 steps.</li> <li>• This is extension head rest bracket with head tilt mechanism.</li> </ul>	
 <p data-bbox="306 2056 427 2087">HRB 1401</p>	<ul data-bbox="762 1783 1069 1971" style="list-style-type: none"> <li>• 5 steps ratchet operation.</li> <li>• This is a simple ratchet joint commonly used for arm or head rest.</li> <li>• Bend angle 90°-180°</li> </ul>	

